

**PROCESS INSTRUCTIONS FOR INSTALLING POSITIONER FOR CIRCULAR CONNECTOR CRIMP PIN**

1	Tools Needed	<p><b>TOOL:</b> DMC M22520/07-01</p>  <p><b>POSITIONER:</b> RR-58000-X2003</p> 
2	Remove DMC positioner by removing and retaining 2 screws	
3	Install new positioner	

DATE	CONTROL NUMBER	WRITTEN BY	QUALITY VERIFICATION
07 / 14 / 2020	1041	R. WESSLEY	

